



Příklad nastavení hodinek na přesný datum a čas. Ukázkové parametry jsou **pátek/FRI, 11. listopadu/NOV, 6:30**. Tyto hodnoty jsou jen ukázkové, lze nastavit vámi požadované hodnoty. Pro nastavení hodinek budete potřebovat pomůcku pro zmáčknutí tlačítka na boku pouzdra (korektor). Použit lze párátko či jiný plastový hrot.

#### Postup bezpečného nastavení datového mechanismu:

- Hodinky vezměte do ruky a vytáhněte korunku do poslední, **třetí**, polohy (poloha řízení ruček).
- Korunkou otáčejte směrem k sobě tak, aby se ručky pohybovaly směrem vpřed (ve směru otáčení hodinových ručiček). Sledujte ručku na **24hodinové stupnici** (ručka v ciferníku u 9 hodiny) a otáčejte korunkou, dokud nebude ručka ukazovat na **12 hodinu**.
- Pokud máte nastaveno, **zatlačte korunku** do první polohy (poloha natahování hodinek).

V tuto chvíli máte nařízené hodinky tak, že jsou všechny datumové mechanismy bezpečně seřízeny a můžete pokračovat v nastavení hodinek.

Hodinky jsou teď nařízené na poledne, to znamená, že **velké ručky** ukazují směrem nahoru na **12 hodinu** a malá **24hodinová ručka** ukazuje opačným směrem na **12 hodinu** v malém číselníku.



#### Postup seřízení hodinek

- Vytáhněte korunku do **druhé polohy** (poloha řízení: měsíční fáze, datumu v měsíci a měsíce v roce). Připravte si pomůcku pro zmáčknutí tlačítka na boku pouzdra.
- Otáčejte korunkou **směrem od sebe**. Tím nařídíte **měsíční fázi**. Číselník se nachází na **6 hodině**. Ručkou lze točit jen jedním směrem. Pokud přejedete, točte dál, dokud se nedostanete na požadovanou fázi měsíce.
- Následně otáčejte korunkou směrem k sobě. Tím nařídíte **den** v měsíci (ručka která má na konci červený měsíc a ukazuje na stupnici 1. až 31.) a **měsíc** v roce (pravé obdélníkové okénko na 12. hodině). Měsíc se přehodí vždy, když přejedete ručkou přes číslo 31. Korunkou otáčejte, až se v okénku objeví **NOV/listopad**. Tím máte nastavený měsíc. Teď otáčejte korunkou stále směrem k sobě až na požadované datum 11. Pokud přejedete požadovaný den, musíte proces opakovat a projet všechny měsíce znovu. Pokud máte nastaveno, s korunkou teď nehýbejte. Vezměte si párátko nebo nějakou pomůcku s tenkým hrotem a lehkým stlačením bočního tlačítka na straně hodinek u čísla 10 přecvakujte den v týdnu na požadovaný den, v tomto případě **FRI/pátek** (levé horní obdélníkové okénko u čísla 12).
- Zkontrolujte, že je vše nastavenou správně. Následně vytáhněte korunku do **třetí** (poslední) polohy (poloha řízení ruček) a zkontrolujte, že jste si nezměnili datum.
- Pokud je datum nastavený na 11. listopadu, zbývá nastavit čas. Ověřte si, že velké ručky vám směřují na 12. hodinu a malá 24hodinová ručka směřuje směrem dolů také na 12 hodinu. To znamená, že jste přesně na poledni (12:00).
- Teď točte s vytaženou korunkou na jednu, anebo druhou stranu (ručkami ve směru nebo protisměru hodinových ručiček) a nastavte aktuální čas podle toho, jestli se nacházíte v dopoledních hodinách nebo odpoledních. V tomto případě nařizujeme 6:30. S korunkou tedy točíme směrem od sebe (ručky se otáčí v protisměru otáčení hodinových ručiček) dokud nedojedeme ručkami na 6:30.
- Pokud máte nařízeno zatlačte korunku do první polohy (poloha natahování hodinek) a párkrát lehce otočte korunkou směrem od těla. Tím hodinky dotáhneme.
- Hodinky jsou teď nastaveny na **pátek/FRI, 11. listopadu/NOV, 6:30**, lehce dotažené a připravené na použití.



#### Doporučení

- Nikdy nenastavujte korektorem hodinky, ani dny v týdnu, pokud malá 24hodinová ručička směřuje mezi 22. a 6. hodinu. Tím poškodíte datumový mechanismus, který se musí následně opravit/vyměnit.
- Nepohybujte velkými ručkami v protisměru otáčení hodinových ručiček přes 12. hodinu (půl noc - 24:00). Rozhodíte si nastavený datum a může dojít k poškození datumového mechanismu.
- Pokud chcete dosáhnout stabilnějšího chodu hodinek, doporučujeme hodinky před nasazením na ruku párkrát natáhnout. Pokud je nemáte právě vytažené z automatického natahovače.
- Při použití natahovače: Natahovač musí mít správně nastavený režim tzn. správný směr otáčení (v protisměru otáčení hodinových ručiček).
- Tlačítka pro chronograf nikdy nepoužívejte pod vodou. Může dojít k napumpování vody do hodinek.

## Detailní návod na seřízení hodinek PRIM Tycho Brahe kal. 77.51



www.prim.cz

ELTON  
HODINÁŘSKÁ A.S.



## Detailed guide for setting The PRIM Tycho Brahe cal. 77.51



www.prim.cz



This is an example showing you how to set the precise date and time on your watch. The sample parameters used for this example are **Friday/FRI, November/NOV 11, 6:30 AM**. These values serve merely as an example, feel free to use any values you need. To set the date and time, you will need a tool for pressing the side button on the case (the corrector). Any tool with a narrow end can be used to press the button gently and carefully. **CAUTION:** Never use sharp-tipped tools that could damage the button.

### Steps to safely adjust the calendar complication (display):

- Hold the watch in your hand and pull the crown out into its outermost, **third**, position (hand control position).
- Rotate the crown towards you, so that the hands move forward (clockwise). Carefully watch the **hour hand** (hand of the dial at the 9 o'clock marker) and rotate the crown until this hand points at the **12 o'clock marker**.
- Once you are done, **push the crown** into its first position (winding position).

At this point, your watch is set in a way ensuring that all the calendar complications are safely adjusted, allowing you to proceed in setting your watch.

The watch is currently set to noon, which means that the **minute hand** is pointing towards the **12 o'clock marker** and the **small hour hand** is pointing in the opposite direction, towards the **12 o'clock marker** on the small dial.



### Steps to set your watch

- Pull the crown out into its **second position** (position for setting moon phase, date, and month in the year). Prepare a tool for pressing the side button on the case.
- Rotate the crown **away from you**. This will set the **moon phase**. Its dial is located near the **6 o'clock marker**. This hand turns in one way only. If you overshoot, simply continue turning until it indicates the correct moon phase.
- Then, rotate the crown towards you. This will set the date (the hand with the red crescent on the end, moving along the scale from 1-31) and month (the right rectangular window at the 12 o'clock marker). The month will change every time you cross the 31 marker. Rotate the crown, until the month window shows **NOV/November**. And with that, you have successfully set the month. Now rotate the crown, still towards you, until you reach the desired date, the 11th in this case. If you overshoot and miss the right date, you have to repeat the entire process and go past all the other months again. If you have it set, avoid moving the crown for now. Take a toothpick, or similar tool with a thin tip, and gently press down the side button on the case near the 10 o'clock marker to cycle through the days of the week until you reach the right one, which is **FRI/Friday** in this case (upper left rectangular window near the 12 o'clock maker).
- Verify that all the values are set correctly. Then, pull the crown out to its third (last) position (position for hand control) and confirm that the date remained unchanged.
- If the date is set to November 11, all that remains is to set the time. Verify that the minute hand is pointing at the 12 o'clock marker and that the small hour hand is pointing downwards, towards the 12 o'clock marker. This means that, according to the watch, it is precisely noon (12:00 PM).
- Now rotate the still pulled-out crown one way or the other (clockwise or counterclockwise) and set the current time, depending on the actual time and whether it is still morning or afternoon. In this case, we want to set the time to 6:30 AM. Thus, we rotate the crown in the direction away from us (hands turn counterclockwise), until the hands reach 6:30 AM.
- Once you set the time, push the crown into its first position (winding position) and gently rotate the crown away from you a few times. With that, we have ensured the watch is properly wound.
- The watch is now set to **Friday/FRI, November/NOV 11, 6:30 AM**, slightly wound and ready to be used.



### Recommendations

- Never use the corrector to set the watch, not even the date, if the small hour hand is pointing anywhere between 10:00 PM and 6:00 AM. This will damage the calendar complication mechanism, which would have to be repaired or completely replaced.
- Do not rotate the minute hands counterclockwise across 12 o'clock (midnight - 24:00). This will misalign the set date and it might damage the calendar complication mechanism.
- If you want your watch operation to be more stable, we recommend winding the watch a few times before you place it on your wrist. Unless you have just taken it out of your automatic watch winder.
- If you use a watch winder: The winder must be properly configured, i.e. it must use the right direction (counterclockwise).
- Never use the chronograph pusher under water. It can pump water into the inner parts of the watch.

ELTON  
FRONASA, A.S.